

OLYMPIC

Party Hire

Olympic Party Hire

63-65 South Road

Thebarton SA 5031

Ph: 08 8346 5545

E: info@olympichire.com.au

GIF Booth Package

Includes – Light Ring, I Pad, Tripod, Powercords



1. The iPad log in is – 123456 or 180590
2. Plug Gif booth in and position for your event - remember it does need access to power – you may need an extension cord and power board. Also remember to plug the ipad charger in if using the ipad for a long duration. Tape down excess power cord to reduce the risk of a tripping hazard.
3. Once you've plugged in the Gif booth and turned on connect to the internet. If WIFI is unavailable, you can tether a connection through a phone. Alternatively all photos will be sent once the internet is restored
4. Once its connected go to the 'Snappic' app, select your event & click start photo booth (generally at the bottom right of the app) You can adjust your camera settings as this starts however it is advised to go with the recommended settings on the screen! Your guests can choose between texting, emailing or sending via social media their photos/GIFs.
5. All photos & GIFs will be sent as a file to you at the end of your event (generally 2-3 days afterwards)

If you have any questions, feel free to call our office on 8346 5545.